

Remove the end cap off the baton. Then Screw on the LED light attachment to baton.



LED light attaches to end of the baton



Twist the end of the flashlight to turn the light on or off.

Refer to the image below to replace the battery. The required battery for replacement is 1 CR-123A.

